
# Panasonic



Panasonic's new KX-T7710 proprietary telephone is stylish, easy to use, and affordable. Equipped with a large, convenient One-touch Button Panel, Message/Ringer Lamp and Data Port, the KX-T7710 is ideal as an office or hotel room phone. A number of additional functions are available when connected to a Panasonic PBX system.



## Message/Ringer Lamp and One-Touch Call Return

The KX-T7710's message/ringer lamp helps you catch all the important calls -- even when you're not within earshot of the phone. A large, easy-to-see orange light illuminates to visually alert you when a call comes in or when someone has left a message. It's easy to return calls, too. When the KX-T7710 is

connected to a Panasonic PBX and set to PBX mode, simply press the message button to automatically call back the person who left a message.



### Data Port for Connecting a Communication Device

A second jack on the right side of the phone lets you connect a computer, modem, fax machine, answering machine, or other single-line device. An RJ11 modular jack is available.



#### Flash/Recall

Used to send a flash signal in order to access a PBX feature (ex., Hold, Transfer, or Three-party Conference).

<u>Redial</u>

Used to redial the last dialled number.

**Pause** (Normal mode) Used to insert a pause when storing a telephone number.

Auto (Normal mode) Used for Speed Dialling.

**Program (Normal mode)** Used to enter the programming mode.

Wall Mountable

If there's no suitable desk space for your KX-T7710, simply mount it on the wall.

#### **3-Step Ringer Selector**

You can adjust the ringer volume in three steps (low/middle/high).

# Panasonic

# One-Touch Buttons for Quick, Easy Dialling

The KX-T7710's one-touch buttons save you time and trouble when calling a client, customer, or associate you often speak with. Simply press one of the eight\* one-touch buttons and the KX-T7710 instantly dials. When using a Panasonic PBX system\*, you can preset the one-touch buttons at the PBX system. A hotel, for example, can set these buttons to call the front desk, housekeeping, or room service, and guests are unable to change them.

\* There are eight one-touch buttons in PBX mode, five in Normal mode.
\* Depending on the PBX model and version. Consult your Panasonic dealer for details.



#### **Specifications**

|                        | PBX Mode                            | NORMAL Mode |
|------------------------|-------------------------------------|-------------|
| Programmable           | -                                   | Yes         |
| One-touch Buttons      | 8                                   | 5           |
| Speed Dialling         | -                                   | 10          |
| Flash/Recall           | Yes                                 | Yes         |
| Auto                   | -                                   | Yes         |
| Pause                  | -                                   | Yes         |
| Handset Volume Control | Up/Down Key (3 steps)               |             |
| Ringer Volume Control  | Slide Switch (Low/middle/high)      |             |
| Line Connection        | 1-pair analogue/RJ11 (center 2-pin) |             |
| Data Port              | RJ11                                |             |
| Dial Mode              | DTMF only                           |             |
| Memory Capacity        | 22 digits                           |             |
| Pause                  | 5 seconds                           |             |
| Flash                  | programmable                        |             |
| Wall Mountable         | Yes                                 |             |
| Dimensions (mm)        | 170 x 219 x 84                      |             |
| Weight (kg)            | 0.6                                 |             |



